
ASSEMBLY INSTRUCTIONS



Calais Large Semi-Flush

Item # NW4051

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):


Phillips Screwdriver Slotted Screwdriver

- 1. Carefully remove all parts from the box. Place on a clean, soft surface.
- 2. Remove mounting plate **(B)** from fixture **(E)** by removing threaded caps **(F)**.
- 3. Install mounting plate **(B)** to the junction box and secure with mounting screws **(D)**.
- 4. Wrap fixture ground wire (bare copper) around the green grounding screw (see diagram 1). Tighten. Continue fixture ground wire and connect to supply ground wire (usually green or bare copper) using wire nut (A).
 - **NOTE:** It is imperative that the fixture is grounded.
- 5. Connect fixture neutral wire (white) to the supply neutral wire (usually white) using wire nut (A).
- 6. Connect fixture hot wire (black) to the supply hot wire (usually black) using wire nut (A).
 - **CAUTION:** Do not reverse the hot and neutral connections.
- 7. Make sure all wire connections are tight, then carefully tuck into the junction box.
- 8. Install fixture **(E)** to mounting plate **(B)** and secure with threaded caps **(F)**.





ASSEMBLY INSTRUCTIONS



Calais Large Semi-Flush

Item # NW4051

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

9. Install light bulbs into the sockets.

To replace the broken glass rods:

- 1. Make steel wire straight by using the plier, then remove the bead and broken glass rod.
- 2. Let the intact glass rod and bead pass through the steel wire.
- 3. Make the steel wire rolled up by using the plier.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.



